


FAR SIDE CURB BUMP-OUT
WITH
APPROACH LANE CURB TAPER



NEAR SIDE CURB BUMP-OUT
WITH OR WITHOUT
FAR SIDE CURB BUMP-OUT

NOTES:

- 1. APPROACH CURB TAPER IS TO BE UTILIZED ON APPROACH SIDE WHEN ON-STREET PARKING WILL NOT BE IMPACTED. TAPER LENGTH SHALL BE DESIGNED TO MEET MUTCD STANDARDS.
- 2. APPROACH SIDE LANE CURB TAPER MAY BE REPLACED WITH PAVEMENT MARKINGS ONLY WHEN SHOWN ON PLANS AND APPROVED BY CITY ENGINEER.
- 3. TOTAL NUMBER AND LOCATION OF DELINEATORS WILL BE AS REQUIRED IN CONTRACT PLANS, OR AS ORDERED BY PROJECT MANAGER.
- 4. DELINEATORS ARE TO BE PROVIDED AT BOTH ENDS OF BUMP-OUT/RECESSED PARKING AREA.
- 5. DELINEATORS ARE TO BE CENTERED 12 INCHES OFF BACK OF CURB OR CONCRETE GUTTER.
- 6. SEE DETAIL S609-20 FOR CURB BUMP-OUT DIMENSIONS.
- 7. SEE DETAIL S646-1 FOR DELINEATOR REQUIREMENTS.

CITY OF ROCHESTER

CURB BUMP-OUT INTERSECTION AND DELINEATOR LAYOUT

ISSUED 2-8-13 NON-STANDARD REVISED 11-19-20 DWG.NO.S609-21