

4. CLEAN PAVEMENT SURFACE, APPLY TACK COAT AND TREAT ALL EDGES WITH ASPHALT PAVEMENT JOINT ADHESIVE BEFORE CONSTRUCTING RAISED CROSSWALK.

FOR RAISED CROSSWALK OPEN.

RAISED
CROSSWALK
SECTIONS NEW PAVEMENT

ISSUED 8-2-05 NON-STANDARD
REVISED 3-1-17 DWG.NO.S414-2